

TOMAR

Instruction Manual



975L-2604 Scorpion Half-Bar

IS0618-03
10.17.2017

TOMAR Electronics, Inc.
2100 W. Obispo Ave.
Gilbert, AZ 85233 USA

800.338.3133 ph
800.688.6627 fax

www.tomar.com



975L-2604 Wiring

RED	+12Vdc
BLACK	Ground
ORANGE	Warning Mode 1
BLUE	Warning Mode 2
ORANGE & BLUE	Warning Mode 3
RED/WHITE	Right Arrow Mode (Model 2604-C01 Only)
BROWN/WHITE	Left Arrow Mode (Model 2604-C01 Only)
RED/WHITE & BROWN/WHITE	Center Out Arrow Mode (Model 2604-C01 Only)
BROWN	Scene Lights (if equipped)
GREEN	Intensity Control

Programming Instructions

Entering Warning Programming Mode:

Three unique warning patterns can be selected using the ORANGE and BLUE mode selection wires.

ORANGE WIRE = Warning Mode 1

BLUE WIRE = Warning Mode 2

ORANGE & BLUE WIRES = Warning Mode 3

To activate the Warning programming mode, connect the BLACK wire to Ground then simultaneously attach the GREEN wire, the RED wire and the mode selection wire(s) for the mode you want to program to +12Vdc.

Changing Warning Patterns and Flash Rates:

To change the Warning pattern, enter the Warning programming mode as described above, including selecting a mode. Tap the RED/WHITE wire to +12Vdc to advance the flash pattern. See the list of available Warning flash patterns below.

A unique flash rate can be assigned to each Warning mode. To change the flash rate, enter the Warning programming mode as described above, including selecting a mode. Move the GREEN wire from +12Vdc to Ground. Tap the BROWN/WHITE wire to +12Vdc to advance the flash rate. See the list of available flash rates below.

Entering Traffic Direction Programming Mode:

To activate the Traffic Direction programming mode connect the BLACK wire to Ground then simultaneously attach the GREEN wire, RED/WHITE wire and the RED wire to +12Vdc.

Changing Traffic Direction Patterns and Flash Rates:

To change the Traffic Direction pattern, enter the Traffic Direction programming mode as described above. Tap the BROWN wire to +12Vdc to advance the flash pattern. See the list of available Traffic Direction patterns below.

A unique flash rate can be assigned to the Traffic Direction mode. To change the flash rate, enter the Traffic Direction programming mode as described above. Move the GREEN wire from +12Vdc to Ground. Tap the BROWN wire to +12Vdc to advance the flash rate. See the list of available flash rates below.

Flash Rates:

- 1) SINGLE FLASH
- 2) DOUBLE FLASH
- 3) NEOBE FLASH
- 4) SCROLL FLASH - switches between the Single, Double and Neobe flash rates:
for Warning patterns, every 4 seconds
for Traffic Direction patterns, every two cycles of a pattern

Flash Patterns, Warning Modes - Model 2604-01

- 1) OFF
- 2) COMBINATION (Patterns 5,4,6,4 repeat) *** ORANGE Wire (Warning Mode 1) DEFAULT, SCROLL FLASH
- 3) INBOARD OUTBOARD *** BLUE Wire (Warning Mode 2) DEFAULT, SCROLL FLASH
- 4) LEFT RIGHT *** ORANGE & BLUE Wires (Warning Mode 3) DEFAULT, SCROLL FLASH
- 5) ALTERNATE
- 6) RANDOM
- 7) SINGLE OUTBOARD
- 8) SINGLE INBOARD
- 9) SWEEP

Flash Patterns, Warning Modes - Model 2604-C01

- 1) OFF
- 2) COMBINATION (Patterns 5,4,6,4 repeat) *** ORANGE Wire (Warning Mode 1) DEFAULT, SCROLL FLASH
- 3) INBOARD OUTBOARD *** BLUE Wire (Warning Mode 2) DEFAULT, SCROLL FLASH
- 4) LEFT RIGHT *** ORANGE & BLUE Wires (Warning Mode 3) DEFAULT, SCROLL FLASH
- 5) ALTERNATE
- 6) RANDOM
- 7) SINGLE OUTBOARD
- 8) DOUBLE OUTBOARD
- 9) SINGLE INBOARD
- 10) DOUBLE INBOARD
- 11) SWEEP

Flash Patterns, Warning Modes - Model 2604-02, 2604-02P

1) OFF		
2) COMBINATION (<i>Patterns 6,5,7,5 repeat</i>)	WITH SL's	*** ORANGE Wire (Warning Mode 1) DEFAULT, SCROLL FLASH
3) COMBINATION 2 (<i>Patterns 12,11,13,11 repeat</i>)	WITHOUT SL's	*** BLUE Wire (Warning Mode 2) DEFAULT, SCROLL FLASH
4) INBOARD OUTBOARD	WITH SL's	
5) LEFT RIGHT	WITH SL's	*** ORANGE & BLUE Wires (Warning Mode 3) DEFAULT, SCROLL FLASH
6) ALTERNATE	WITH SL's	
7) RANDOM	WITH SL's	
8) SINGLE OUTBOARD	WITHOUT SL's	
9) SWEEP	WITH SL's	
10) INBOARD OUTBOARD	WITHOUT SL's	
11) LEFT RIGHT	WITHOUT SL's	
12) ALTERNATE	WITHOUT SL's	
13) RANDOM	WITHOUT SL's	
14) SWEEP	WITHOUT SL's	

Flash Patterns, Warning Modes - Model 2604-C02

1) OFF		
2) COMBINATION (<i>Patterns 6,5,7,5 repeat</i>)	WITH SL's	*** ORANGE Wire (Warning Mode 1) DEFAULT, SCROLL FLASH
3) COMBINATION 2 (<i>Patterns 14,13,15,13 repeat</i>)	WITHOUT SL's	*** BLUE Wire (Warning Mode 2) DEFAULT, SCROLL FLASH
4) INBOARD OUTBOARD	WITH SL's	
5) LEFT RIGHT	WITH SL's	*** ORANGE & BLUE Wires (Warning Mode 3) DEFAULT, SCROLL FLASH
6) ALTERNATE	WITH SL's	
7) RANDOM	WITH SL's	
8) SINGLE OUTBOARD	WITHOUT SL's	
9) DOUBLE OUTBOARD	WITHOUT SL's	
10) SINGLE INBOARD	WITHOUT SL's	
11) SWEEP	WITH SL's	
12) INBOARD OUTBOARD	WITHOUT SL's	
13) LEFT RIGHT	WITHOUT SL's	
14) ALTERNATE	WITHOUT SL's	
15) RANDOM	WITHOUT SL's	
16) SWEEP	WITHOUT SL's	

Flash Patterns, Warning Modes - Model 2604-C02P

- | | | |
|--|--------------|--|
| 1) OFF | | |
| 2) COMBINATION (Patterns 6,5,7,5 repeat) | WITH SL's | *** ORANGE Wire (Warning Mode 1) DEFAULT, SCROLL FLASH |
| 3) COMBINATION 2 (Patterns 14,13,15,13 repeat) | WITHOUT SL's | *** BLUE Wire (Warning Mode 2) DEFAULT, SCROLL FLASH |
| 4) INBOARD OUTBOARD | WITH SL's | |
| 5) LEFT RIGHT | WITH SL's | *** ORANGE & BLUE Wires (Warning Mode 3) DEFAULT, SCROLL FLASH |
| 6) ALTERNATE | WITH SL's | |
| 7) RANDOM | WITH SL's | |
| 8) SINGLE OUTBOARD | WITHOUT SL's | |
| 9) SINGLE INBOARD | WITHOUT SL's | |
| 10) SWEEP | WITH SL's | |
| 11) INBOARD OUTBOARD | WITHOUT SL's | |
| 12) LEFT RIGHT | WITHOUT SL's | |
| 13) ALTERNATE | WITHOUT SL's | |
| 14) RANDOM | WITHOUT SL's | |
| 15) SWEEP | WITHOUT SL's | |

Flash Patterns, Traffic Direction Modes - 2604-C01

- | | |
|---------------------------|--|
| 1) FULL 6 LED ARROW FILL | *** RED/WHITE and/or BRN/WHITE Wires (all Arrow Modes) DEFAULT, SINGLE FLASH |
| 2) FULL 6 LED ARROW TRAIL | |

Flash Patterns, Traffic Direction Modes - Models 2604-01, 2604-02, 2604-02P, 2604-C02, 2604-C02P

NONE

